





Thermo Scientific Orion 2100 Series Analyzer Panel Mounting Kit, Cat. No. 2100SMK

Configuration 2, Rear Attachment



Mounting Specifications

All dimensions are in inches, with a tolerance of ± 0.01 inch.



Mounting Instructions

1. Cut an opening in the panel according to the specifications on the previous page.
2. Insert the 1/4" jackscrews (**item 4**) into the mounting bracket (**item 3**).
3. Slide the 1/4" washers (**item 6**) and loosely thread the 1/4" nuts (**item 5**) approximately halfway onto the jackscrews.
4. Assemble the clamp bars (**item 7**) to the ends of the jackscrews. Align the threaded holes on the clamp bars with the jackscrews and thread the jackscrews into the clamp pads until they are hand tight.
5. Slide the gasket (**item 2**) onto the monitor housing (**item 1**).
6. Assemble the monitor into the panel opening from the front side of the panel.
7. Attach the mounting plate (**item 3**) to the back of the monitor housing and secure the two parts with four #8 screws (**item 8**) and four washers (**item 9**).
8. Push jackscrews (**item 4**) until the clamp pads (**item 7**) are tight against the back surface of the panel.
9. Tighten the 1/4" nuts (**item 5**) against the mounting bracket (**item 3**) to secure the clamp pads to the back of the panel.



©2009 Thermo Fisher Scientific Inc. All rights reserved. All trademarks are the property of Thermo Fisher Scientific Inc. and its subsidiaries.



Process Water Instruments

North America
166 Cummings Center
Beverly, MA 01915 USA
Toll Free: 1-800-225-1480
Tel: 1-978-232-6000
Dom. Fax: 1-978-232-6015
Int'l Fax: 978-232-6031

Europe
P.O. Box 254, 3860 AG Nijkerk
Wallerstraat 125K, 3862 CN
Nijkerk, Netherlands
Tel: (31) 033-2463887
Fax: (31) 033-2460832

Asia Pacific
Blk 55, Ayer Rajah Crescent
#04-16/24, Singapore 139949
Tel: 65-6778-6876
Fax: 65-6773-0836

www.thermo.com/processwater